


# SECTION VI DIAGRAMS



- NOTES:
- \* DENOTES CALIBRATION ITEM, MOST FREQUENT VALUE SHOWN.
  - ALL CAPACITANCE VALUES ARE IN MICROFARADS AND ALL RESISTANCE VALUES ARE IN OHMS, UNLESS NOTED OTHERWISE.
  - DENOTES INTERNAL ADJUSTMENT.
  - DENOTES FRONT PANEL MARKINGS.
  - DENOTES REAR PANEL MARKINGS.
  - SIO, S11, S12, S13 ARE SHOWN IN MAX CCW POSITION.




Figure 6-1. Model 6130A Time Mark Generator,  
Schematic Diagram (Sheet 1 of 2)




Figure 6-1. Model 6130A Time Mark Generator,  
Schematic Diagram (Sheet 2 of 2)